



AMERICANA INSTALLATION INSTRUCTIONS

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

Follow all NEC guidelines and local electrical codes.

NOTE: LISTED FOR OUTDOOR USE ONLY.

This Americana Outdoor Lighting fixture uses LED bulbs that has an operating voltage range of 10.5 - 18 Volts AC. Americana Outdoor Lighting recommends using a 15 Volt tap.


WARNING - RISK OF ELECTRIC SHOCK: This fixture must not be installed within 10FT (3.05m) of a pool, spa or fountain.

Low voltage wire is intended for shallow burial only and should be at a maximum depth of 6 inches (152mm).

FIXTURE INSTALLATION (SEE FIGURE 1.)

1. To prevent electrical shock, unplug transformer from the electrical outlet before installation or service of Fixture.
2. Run the Fixture Leads through the top of the Ground Stake and thread Luminaire onto the Ground Stake.
3. Drive the Fixture / Ground Stake assembly into the ground at the desired location (using a hammer on the edge of the Ground Stake if necessary).
4. Strip the two Fixture Leads to the appropriate length and attach them to the Main Supply Lines using Listed Wet Location Wire Connectors. To protect the wire connection, route the wire in close proximity to the Fixture.

FIGURE 1.



SUITABLE FOR UPWARD LIGHTING ONLY.

IF INSTALLED IN A MANNER NOT OUTLINED IN THIS DOCUMENT, FACTORY WARRANTY MAY BE VOID.

NOTES:

***Use only wire connectors Listed for wet locations. Contact Americana Outdoor Lighting for suitable connectors. (888-358-7233)

***If additional wire is needed to connect the fixture to the low voltage transformer, contact Americana Outdoor Lighting. (888-358-7233)



If you have any questions regarding installations, please call 888-358-7233 and our knowledgeable staff will assist you.